

Cali Avanti User Guide

Setting a programme

Setting the actual background & comfort temperatures is not required at this stage

To set or change a program complete the above procedure for setting the time.

Once the minutes have been confirmed using button **(A)** to confirm a black bar **|** will flash next to the '0' on the 24 hour day line.

By pressing **(-)** or **(+)** select the required period for background or comfort temperature. **i.e by pressing the **(-)** button 7 times will give you 7 hours of background heat. Pressing **(+)** button 3 times will give 3 hours of comfort heat.**

Complete the full 24 hour period using **(-)** or **(+)**

Once you're happy the full 24 hour is completed as required press **(A)** to confirm and the day **•** will move to the next day.

Repeat until 7 days are completed


Mode **(A)** Button

Pressing **(A)** will give you the various operating modes of the radiator.

 **Timer** - use this to run your program

 **House** - only for use with an external programmer

 **Comfort temperature setting** - Set this using **(-)** or **(+)**

 **Background temperature setting** **(-)** or **(+)**

 **Frost temperature setting (7 degrees)**